




HRV/ERV INSTALLATION &
BALANCING FUNDAMENTALS
manual



HRV/ERV INSTALLATION & BALANCING FUNDAMENTALS

First Edition (2019 Edition)

Copyright © 2019, All Rights Reserved Heating, Refrigeration and Air Conditioning Institute of Canada



NOTES



FOREWORD

The HRV/ERV Installation & Balancing Fundamentals manual has been developed and published by the Heating, Refrigeration and Air Conditioning Institute (HRAI) of Canada. Reproduction in any form, whether written, electronic or mechanical, is forbidden.

The careful use of this manual should result in the satisfactory installation and balancing of residential mechanical ventilation systems. However, the end result is in no way warranted by either the Heating, Refrigeration and Air Conditioning Institute of Canada or any companies or any persons involved in the preparation or presentation of this manual.

First Edition Second Printing, December 2019

Copyright © 2019, All Rights Reserved Heating, Refrigeration and Air Conditioning Institute of Canada 2350 Matheson Blvd. East, Suite 101 Mississauga, ON L4W 5G9

ACKNOWLEDGEMENTS

The Heating, Refrigeration and Air Conditioning Institute of Canada would like to thank Francis Belle, Tom Cates and John Harris technical writers and consultants in the development of this manual.

The Heating, Refrigeration and Air Conditioning Institute of Canada would also like to acknowledge the use of equipment specifications and literature from the following equipment manufacturers:

Air King

Aldes Canada

Broan-Nutone

Fantech

Lifebreath

Reversomatic

Thermolec

VanEE



TABLE OF CONTENTS

Foreword	111
Acknowledgements	iv
Table of Contents	v
Purpose	vi
Installation Guide	1
Equipment Location	1
Ducting	2
Condensate	3
Exterior Hoods	
Interior Grilles and Diffusers	5
Dampers	6
Controls	6
System Start-up Guide	7
Visual Review	
Testing Basic Operation	9
Occupant Documentation	10
Airflow Measurement and Balancing Guide	11
Air Pressure Manometers	
Measuring Airflow in Ducts	
HRV/ERV Balancing Procedure	
HRV/ERV Balancing Report	21
Measuring Airflow at Grilles and Diffusers	23
Service Procedures	27
General Approach	27
Maintenance Schedule	29
Checklist	33
Sample Designs	43
CSA F326 Ventilation Design	43
NBC Ventilation Design	46
OBC Ventilation Design	49
Equipment Specifications	51

PURPOSE

The HRV/ERV Installation and Balancing Manual is intended to instruct members of the heating, ventilating and air conditioning industry in the proper installation and balancing of residential mechanical ventilation systems using heat or energy recovery ventilators (HRV/ERVs). It is generic enough in nature that the methods can be used for other ventilation equipment such as bathroom fans.

The manual is meant for industry personnel who have a good basic understanding of HVAC equipment and ductwork installation.

.